

Operation of Switches

William Lucid 04/02/2023

Switch pin assignments:

Switch1Pin GPIO13 //Switch 1

Switch2Pin GPIO14 //Switch 2

Switch3Pin GPIO23 //Switch 3

1. **Wake up from Deep Sleep:** Press and release, quickly Switch 1 (GPIO23) once; Serial Monitor will show start up detail.
2. **Switching effects:** Press and release, quickly Switch 3 (GPIO23) once, then press and release, quickly Switch 2 (GPIO14) twice. Motion function will start.
3. **Entering Deep Sleep:** Must be interrupted when running "noMotion". Red and Blue leds, both "ON", Press and release, quickly Switch 3 (GPIO23) once, then press and release, quickly Switch 1 (GPIO13) once. Blue led will turn "OFF"

Project: MPU6050_WLED_withThree_Switches_1600 04/01/2023